



Girder size & spacing



Sp 1 A A A A A A A A A A A A A A A

1.8' 2.1' 2.0' 2.0' 2.1' 2.0' 1.9' 2.1' 2.0' 2.0' 2.0' 2.0' 2.0' 2.0' 1.6'

Sp 2 A A A A A A A A A A A A A A A

1.6' 2.0' 2.0' 2.0' 2.0' 2.1' 1.9' 2.0' 2.0' 2.1' 2.0' 2.0' 2.1' 1.8'

Sp 3 B B B B B B

5.33' 5.33' 5.33' 5.33' 5.33'

Sp 4 A A A A A A A A A A A A A A A

2.0' 2.0' 2.0' 2.0' 2.0' 2.0' 2.0' 1.9' 2.0' 2.1' 1.9' 2.1' 1.9' 1.5'

Sp 5 A A A A A A A A A A A A A A A

1.5' 1.9' 2.1' 1.9' 2.1' 2.0' 1.9' 2.0' 2.0' 2.0' 2.0' 2.0' 2.0' 2.0' 2.0'